



Einhell



Robot Lawn Mower

FREELEXO CAM PLUS 550

Item No.: 3414005



Ident No.: 21014

Bar Code: 4006825682700

The Einhell FREELEXO CAM PLUS 550 is part of the Power XChange family, where all parts can be combined with each other. Using an integrated camera and sensors, the FREELEXO CAM PLUS 550 can identify the boundaries of the lawn areas to be mowed automatically by detecting lawn areas based on colours and structures. In addition, areas can quickly be excluded using magnetic tape. In addition, it is equipped with Wi-Fi for connection to the Einhell Connect app as well as an LCD display and a keypad for programming on the device. The robot lawnmower is designed for areas of up to 550 m² in size. The scope of supply includes a 3.0 Ah Power XChange Plus battery, a charging station and suitable installation equipment.

Features & Benefits

- A member of the Power XChange family, 1 x 18 V battery required
- Brushless motor – more power and longer running time
- The robot lawnmower detects the mowing area with its integrated camera
- Option for individual robot lawnmower control via app
- Intuitive operation keypad and LCD display
- Programmable mowing times
- Over-the-Air updates: automatic updates via Wi-Fi
- Automatic: Automatic return to charging station and charging process
- Safety sensorics provided by shock, tilt and lift sensors
- Integrated rain sensor
- Anti-theft feature thanks to PIN code
- Cutting height can be individually adjusted
- Suitable for gradients of up to 25%
- Second area mode: Mowing programme for adjacent areas
- Carrying handle for comfortable transportation
- Lawns up to 550 m² in size
- Incl. 25 x fastening hooks
- Incl. 2 x connecting clamps and 3 x replacement blades
- Includes 1 x 3.0 Ah Power XChange Plus battery and a charging station



Technical Data

- | | |
|-----------------------------|--------------------------|
| - Power | 18 V |
| - Cutting width | 18 cm |
| - Slope | 25 % |
| - Spare blades | 3 |
| - Connecting clamps | 2 pcs |
| - Hooks | 25 pcs |
| - Recommended area | 550 m ² |
| - Guide wire | 12 m |
| - Accumulator | 18 V 3000 mAh Li-Ion |
| - Cutting height adjustment | 20 mm/60 mm |

Logistic Data

- Pieces per export carton	1 pcs
- Gross weight of export carton	16.24 kg
- Gross weight (kg)	16.24
- Product weight (kg)	9.5
- Container quantities (20"/40"/40"HC)	294 602 688
- Dimensions export carton	700 x 445 x 325 mm
- Dimensions single packaging	705 x 445 x 320 mm

Available as special accessories



Replacement Blades Set, 12 pcs.
Robot Lawn Mower Accessory
Item No.: 3414020
Bar Code: 4006825648775
Einhell Accessory



50 m Perimeter Wire
Robot Lawn Mower Accessory
Item No.: 3414021
Bar Code: 4006825648782
Einhell Accessory



Connecting Clamps, 4 pcs.
Robot Lawn Mower Accessory
Item No.: 3414022
Bar Code: 4006825648799
Einhell Accessory



Fastening Hooks, 100 pcs.
Robot Lawn Mower Accessory
Item No.: 3414023
Bar Code: 4006825648805
Einhell Accessory



Robot Lawn Mower Garage
Robot Lawn Mower Accessory
Item No.: 3414024
Bar Code: 4006825654417
Einhell Accessory



Cleaning Kit
Robot Lawn Mower Accessory
Item No.: 3414025
Bar Code: 4006825657951
Einhell Accessory



Repair Kit
Robot Lawn Mower Accessory
Item No.: 3414026
Bar Code: 4006825657968
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



PXC 18V 2,0Ah
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



PXC 18V 5,2Ah
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 3,0Ah
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC+ 18V 4-6Ah MULTI
Battery
Item No.: 4511502
Bar Code: 4006825644210
Einhell Accessory



PXC 18V 2,5Ah
Battery
Item No.: 4511516
Bar Code: 4006825650518
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
C1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



18V 4,0Ah PXC Starter Kit C1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 5,2Ah & Twincharger Kit
PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory